

ASSEMBLY INSTRUCTION: CABINET QUEEN BED Step 3 Step 4 I x 24/4 Step 5 Finish Step 6 O x 3 P x 1 O x 3 Attention: Don't tighten until all bolts are in place