


WILDING WALLBEDS INSTALLATION INSTRUCTION Side Mount

INSTRUCTION BOOKLET #25




With Storage Head Board


WARNING! ALL MURPY/WALLBED SYSTEMS CONTAIN STORED ENERGY. FAILURE TO USE AND FOLLOW THESE INSTRUCTIONS DURING THE INSTALLATION PROCESS COULD RESULT IN SEVERE PERSONAL INJURY TO USER OR DAMAGE TO PRODUCT. PLEASE CONTACT CUSTOMER SERVICE AT 866-725-6401 FOR ANY QUESTIONS.

Revision 11/11 BK25

Tools Needed



Ratchet



Step Ladder




1/2" Socket



3/8" Socket




7/16" Socket



Crescent wrench



Phillips screwdriver



1/2" open end wrench




Large regular screwdriver




1/4" wood drill bit




Small regular screwdriver




1/4" Allen wrench



Stud finder











Cordless screw driver
with Phillips bit
















Tape measure

Hardware Page






Bag 7

Item	Qty
 5/16" Plain Hexagon Nut	10
 5/16" Nylock Hexagon Nut	6
 3/4" Cam Washer	2
 7/8" Washer	2
 5/16" x 1 1/4" Flat Head Bolt	10
 5/16" Allen Head Bolt	2
 5/16" x 3/4" Hex Head Bolt	4
 4 mm x 1/4" Flat Head Screw	4


Bag 8

Item	Qty	Item	Qty
 3/16" Nylock Hexagon Nut	16	 1/4" x 3/4" Hex Head Bolt	2
 3/16" Washer	2	 3/4" Flat head Screw	6
 3/16" x 1 1/4" Black Flathead Screw	2	 4 hole corner bracket	4
 1/4" Star Washer	2	 "L" Bracket	3
 5/8" Pan head Screw	135	 Spacer Plate	2 (1 left 1 right)
 3/16" x 1/2" Black Truss head screw	14	 2" Flathead Wood Screw	6
 Leg Stop	2		

Other Hardware

Item	Qty
 Cam Fitting	40
 Connecting Bolts	40
 1/4" Square Drive Wood Screw	160
 3 1/2" Wood Screw	3
 1 1/4" Wood Screw	4

Step 1: Locate the left and right Side Boards and then from the square white box locate the two Lift Mechanisms, hardware bags and springs.



Step 2: Install Springs in the Lift Mechanisms

- The number of springs in the Lift Mechanism required varies with the different weights of mattresses. If you purchased your mattress with your bed from Wilding Wallbeds refer to the chart to the right. This will also be a good reference point for mattresses not purchased with your Wall Bed.

Bed Size	Number of Springs
Queen	6
Full/Double	4
Twin/Single	2

NOTE: After you have completed installing and checking operation of your Wall bed, you may find it necessary to add or remove springs to achieve the correct lift effort of between 5 and 10 pounds.


- Install the first spring in hole #5 (center position) on both the Mounting Plate and the Tension Arm. Hook one end of the spring under the upturned edge of the Mounting Plate. Lay the spring down and slide it under the matching hole in the Tension Arm. See illustration 1.

HELPFUL HINT: You may find it easier to fit the hook under the Tension Arm if you pry up the Arm Bracket with a wooden wedge or similar device.



- Continue by working out from the center, alternating top and bottom, until you have installed the required number of springs.

IMPORTANT! Be sure that holes of the Mounting Plate correspond to the holes in the Tension Arm and use the same number of springs and the same configuration on both Lift Mechanisms

- Repeat Step 2 for Left Lift Mechanism.




Hardware needed for next 2 steps from Bag #7





Step 3: Install the Lift Mechanism by inserting a 5/16" x 1 1/4" Flathead Machine Screw through holes "C" and "D" from the outside (countersunk holes) of the Right Side Board. Position the corresponding Right Lift Mechanism holes. Loosely thread on a 5/16" Plain Hex Nut on each. Insert the same type screw through holes "A" and "B". At hole "A" use one of the Hexagon Cam Washers in the slot of the mounting plate so that the LARGER PART OF THE CAM IS UP. At hole "B" use a 5/16" x 7/8" washer. Thread a nut on each. Tighten the four nuts evenly, making sure the hexagon cam washer does not rotate while tightening. See illustration 2.

IMPORTANT! Over tightening the nuts will pull the head of the screw too deeply into the Side Board. Tighten only until the head of the screw is flush with the Side Board.


Repeat step 3 with the Left Side Board and Lifting Mechanism.




Hardware needed for next step




Step 4: Lay the right and left Side Boards down as illustrated and screw Connecting Bolts into the holes provided and place Cam Fittings into sockets provided as shown.



Hardware needed for next step



Connecting Bolt




Step 5: Locate the Bridge Board and Insert 11 Connecting Bolts into the holes provided. Screw the bolts in until they tight against the bed part.

Hardware needed for next step




Cam Fitting



Step 6: Locate the Bridge Support and Insert 4 Cam Fittings.



Hardware needed for next step




Step 7: Locate the Head Board and insert 6 Cam Fittings into the sockets provided. Then screw 3 Connecting Bolts into holes at the bottom edge of the Head Board.




Step 8: Locate the Head Board bottom and insert 7 cam fittings into the sockets provided.

Hardware needed for next step



Cam Fitting


Step 9: Locate the 2 Stretcher Boards (equal in size) and insert four Cam Fittings into the back of each Stretcher.



Working with Cam Fittings


In the next steps you will work with Cam Fittings and Connecting Bolts in attaching cabinet parts together. Take a minute and review this information for ease of assembly.

- Slide the Cam Fitting over Connecting bolt.
- Hold parts snug together.
- Turn Cam Fitting 1/2 turn clockwise with a manual screw driver. **DO NOT USE POWER SCREW DRIVER.**




Step 10: Assemble the Bed Cabinet face down with the bottom of the bed nearer the wall to which it will be installed by connecting Bridge Board, Head Board, and the two Stretchers as illustrated.

NOTE: The front stretcher is positioned so the cam fittings are on the BOTTOM of the bed.




Step 11: Insert the Head Board bottom into position as illustrated. Note the cam fittings are facing down toward bed bottom.




Step 12: Install the hinged storage door unit as illustrated.

Helpful hint: Lift the center section to get the unit positioned correctly




INSTALLATION WALL


Step 13: Stand the bed cabinet up and leave 2 feet between cabinet and the wall so you have space to work behind the bed



Step 14: Position the Bridge Board as illustrated below. Place it on to the Side Boards and tighten all Cam Fittings.





Step 15: Locate the Front Bridge Support and insert it between the Side Boards and on to the Connecting bolts. Tighten all Cam Fittings.





Part and hardware needed for next step


Locate the metal Bridge Stiffener from the long white cardboard box. There are several (5) parts that look the same as the Stiffener, you will identify it from the others by a length of double stick tape across the top edge.



Step 16: Remove the double stick tape cover and pass the Bridge Stiffener between the Side Boards and up behind the Front Bridge Support. The double stick tape should stick to the bottom of the Bridge Board. Anchor the Stiffener to the Front Bridge Support and the Bridge Board using 3/4" screws through holes in the Stiffener. DO NOT use the lower holes on either end of the Stiffener as illustrated.



Step 17: With Bed cabinet in the standing position open the storage head board on both sides and insert two 1 1/4" gold screws in either side of the lid support through holes provided as shown.



WARNING! THE NEXT STEP MAY REQUIRE PROFESSIONAL HELP.


IF YOUR WALLS ARE NOT TRADITIONAL WOOD FRAMING, YOU MAY NEED TO HIRE A HANDY MAN OR CONTRACTOR TO HELP IN ANCHORING THE BED TO YOUR WALL. FAILURE TO PROPERLY ANCHOR CABINET COULD CAUSE SEVERE PERSONAL INJURY. CALL TECHNICAL SUPPORT AT 866-725-6401 IF YOU HAVE ANY QUESTIONS.

Hardware needed for next step



Step: 18: Using a Stud Finder locate and mark at least 3 studs in the wall behind the bed cabinet. Pre drill with a 1/4" drill bit through the Anchor Support Board at the back of the Bridge Board corresponding with the studs in your wall. Using the 3 1/2" wood screws provided anchor the bed cabinet to the wall through the pre drilled holes.


IMPORTANT! Bed cabinet requires 3 studs, It is VERY important that the bed cabinet be anchored securely to the wall. For technical support call 866-877-7803 toll free.



Important note: It is critical to orient the bed face panels and bed rails in the next 5 steps correctly. All of the renderings (drawings) in the next 5 steps assume that you are looking away from the wall you just installed the cabinet against in the previous step. There is a note under each of the renderings indicating “your bed cabinet installed on this side” which indicates that is where the bed cabinet is in relation to the face panels and rails.


Step 19: Locate the Front Panel(s) and lay them on the floor face down (finished side). Position them in front of where the Bed Cabinet was installed and leave enough room to work around them.

HELPFUL HINT: Two of the panels have holes drilled for handles. Those panels should be the middle two panels with the holes next to each other and away from the bed cabinet installed on your wall.




Step 20: Arrange the mattress rails on the face panels as shown. Rails are in the long white card board box.

HELPFUL HINT: Side mount beds can be slept on in either direction. The rails referred to as “Head/Foot rail” can act as either the head or foot of the bed, depending on which way a sleeper lies.





Hardware needed for next 2 steps from Bag #8




Step 21: From hardware bag 8 locate the hardware shown above. Finger tighten the hardware as shown in illustration 7 attaching two of the 4 hole corner brackets on the Head/Foot rail end of the mattress frame. Note the lower hole on each side rail uses the Leg Stop with the longer screw (3/16" x 1 1/4"). Repeat on the opposite foot rail corner.

Step 22: Once all sides are finger tight go back to each corner and align the corners as they are tightened using either a 3/8" socket or wrench and a Phillips screw driver.








Your bed Cabinet installed on this side

Step 23: Finger tighten the hardware as shown in illustration 8 attaching the 4 hole corner brackets on the inside of the rails and the Spacer Plate is attached on the outside. Repeat opposite Lower Rail corner.




Hardware and parts needed for next steps




Step 24: Using the Spacer Plates as a reference at the lower rail of the Bed Frame, align the Rails and the wood Face Panels. For proper alignment the lower rail should be flush with the Face Panels and the Head/Foot Rails should have a 1" offset top to bottom on both sides. See illustration 9.

Step 25: Using the 3/4" pan head screws secure the Bed Frame (rails) to the Face Panels using 1 screw in each corner first ensuring that the frame and panels are square to each other. Once the Frame is secure insert the balance of the screws around the Rails.




Your bed Cabinet installed on this side


Step 26: Attach the Velcro Straps (for holding the mattress in place) about 12" from the Upper Rail of the bed. Put the hooks part of the strap on one side of the bed and the loops part of the strap on the other side. Insure that the hooks and loops will face each other and interlock. see Illustration 11






Hardware needed for next step from hardware bag #7



Step 27: As illustrated below, insert the Allen Key Bolt through bolt hole # 1 and tighten it down securely using a Nylock Nut. Now insert a 5/16" x 3/4" Hex head bolt through hole # 3 and thread the Nylock nut ONLY UNTIL IT IS FLUSH WITH THE BOLT END. Bolt hole #2 will be used in a later step.




Hardware needed for next step from hardware bag #8




Step 28: Assemble Legs by first removing the nut and the first TWO washers that come pre-installed on the Leg. Leave the washer with a black edge and the thin plastic washer in place on the leg. Insert the Leg Bolt with the first two washers through the Head/Foot Rails. DISCARD the thick silver washer then place the black washer and the nut back on the Leg Bolt and tighten.

Step 29: Position the Cross Bar between the Legs. Place 1/2" Star washer on one of the 5/16 X 3/4" Hex Head bolts apply 2 drops of Loc-tite and thread the bolt through the Leg and into the Cross Bar and tighten. Repeat on other side.




Step 30: Brace one foot against the front edge of the side board and using the 13" length of PVC tubing provided, lever the lift mechanism tension arm out and down until you can secure the arm lock to the hexagon nut shown to right. BE SURE THAT THE LOCK IS SECURED AGAINST THE HEX NUT BEFORE RELEASING THE TENSION ON THE LIFT MECHANISM.

CAUTION! There will be a lot of tension on the Tension Arm. We recommend that two people handle this procedure - one pulling and holding the Tension Arm with both hands while the other sets the Arm Lock. When setting the Arm Lock, DO NOT reach behind the Tension Arm.



IMPORTANT! As instructed in step 27, Bolt #3 should be loose enough to slip into the notch at the end of the Tension Arm See illustration below.

Step 31: Stand the Bed face unit up on its Lower Rail. Now with you and your assistant on either side of the Bed unit lift until the # 3 bolt on the Bed face unit is a few inches above the slotted end of the Tension Arm on both sides. Gently lower the Bed face unit between the Tension Arms and seat the # 3 bolt into the slot at the end of the Tension Arms. Now start pulling the bed face unit down and away from the Bed Cabinet the Allen Key bolt head will seat into the notch at the lower end of the Tension Arms. Lower the bed unit down and pull the Legs down so that they are on the floor. Someone will need to hold the bed unit down as it will want to rise.




Hardware needed for next step from hardware bag #7



Step 32: Insert a 5/16" X 3/4" Hex bolt through hole #2 and tighten a 5/16" Nylock nut onto the bolt. Now tighten the nut and bolt in hole #3.

Repeat step 32 on the other side of the bed unit.

WARNING! Failure to insert and tighten all the bolts in step 32 could result in **severe personal injury** or damage to the lift mechanism. Lift mechanism damage caused by missing or loose hardware is not covered by warranty.




Hardware needed for next step from hardware bag #7




Step 33: Slip the Mechanism Cover over the Mechanism so that the tabs on the cover fit into the notches provided. Line up the holes with the threaded supports and insert two 4mm Flathead screws.

Repeat step 33 on the other Mechanism.



Step 34: When the bed is closed check to see if the gap on either side is the same. If it looks right skip this step. If the gap is not right, meaning that the Bed Box is too close to the side board or even touching it at the top on one side it will need to be adjusted. The procedure will require the bottom of the bed to be moved slightly to the left or right depending on which top corner is too close. If the bed is too close on the top right side for instance, the right side (bottom) will need to be slid to the left slightly. Have one person push the bed at the bottom with his feet while the second person pulls at the opposite bottom side.



Step 35: Attach Bed Handles provided through the pre drilled holes in the two center panels

