

next bed™

ASSEMBLY INSTRUCTIONS

Section 1: LAY OUT PARTS

Unpack and familiarize yourself with the components. Single, Double and Queen size Next Beds™ are packed in 2 boxes. Remove the entire contents of both boxes and lay the components out on the floor in the manner of Diagram 1. Double check the cartons to be sure you have not missed any parts left in the packing materials. The Hardware is organized in the card step by step for convenience. Do not remove hardware or Slat Holders until directed.

Copyright by Murphy WallBed Systems Inc. No part of this publication may be reproduced or transmitted without permission of the Copyright owner.
© 2011 Murphy WallBed Systems Inc.
Patents Pending.

COMPONENT LIST

SINGLE - 38.2"x74.8" (970x1900mm)
DOUBLE - 53.1"x74.8" (1370x1900mm)
QUEEN - 59"x78.7" (1500x2000mm)

A. Mattress Retainer Bar

- Single Bed (1)
- Double & Queen Bed (2)

B. Head Frame (1)

C. Center Rail (Double & Queen Bed)

D. Side Rail (Pair)

E. Leg Actuator Bars (2)

F. End Frame (1)

G. Wall Mount Bracket (2)

H. Floor Yokes (Pair)

I. Yoke Connector Bar (1)

J. Bottom Spring Tube (1)

K. Springs (10)

L. Spring Cover (2)

M. Leg Connector Tube (1)

N. Legs (Pair)

O. Slat Holder

(3-Single, 6-Double or Queen)

O. Opened Slat Holder

(3-Single, 6-Double or Queen)

Self Tapping Screw


(6-single, 12-Double or Queen)

P. NX-1 Hardware Card (1)


NX-2 Hardware Card (1, Double or Queen)
(coordinates with step numbers)

Q. Slats (13-Single, 26-Double, 28-Queen)

Diagram 1.



Slat Holder Bag





Section 2: YOKE ASSEMBLY

Assemble the Yoke Assembly components as shown. If you are installing the bed in a 16" deep cabinet, fasten the Floor Yokes and Wall Mount Brackets together not to exceed a 15" projection from the base board or wall. Secure the Yoke Assembly to the base or wall with the screws provided while following the steps below. *Match fasteners with the actual-size drawings to ensure you use the correct pieces.*



1. Attach the Bottom Spring Tube (J) to the Floor Yokes (H).

M8x16mm Bolt (4pcs)





2. Attach the Wall Mount Brackets (G) to the Floor Yokes (H) using the Bolts, Nuts and Washers shown below. Place bolt heads on outside. Do not tighten bolts now so you can adjust later.

M8x20mm Bolt, 2 Flat Washers, Nylock Nut (4 sets)




3. Attach Yoke Connector Bar (I) to the Floor Yokes (H).

M6x18mm Bolt, Nylock Nut (2 sets)




4. Insert screws through Wall Mount Brackets (G) and into Wall or Base Board at a downward angle.

8-3" (76.2mm) Flat Head Screw (8pcs)




Section 3: BED FRAME ASSEMBLY


5. Feed one end of each Side Rail (D) through the loops of the Nylon Mattress Strap.




6. Slide End Frame (F), Head Frame (B), Side Rails (D) and Center Rail (C) together as shown. Attach End Frame (F) and Head Frame (B) to Side Rails (D); 2 bolts at foot, 4 bolts at head.
M8x53mm Bolt, Lock Washer, Nut (6 sets) -----




7. Attach End Frame (F) to Side Rails at Leg end. Bolts do not go through frame.
M8x16mm Bolt (4pcs) -----



8. Attach End Frame (F) and Head Frame (B) to Center Rail (C). (For Double and Queen Beds only)
M8x55mm Bolt, Lock Washer, Nut (4 sets) -----




9. Attach Slat Holder and Opened Slat Holder (O) to End Frame (F) and Center Rail (C).
One Slat Holder across from one Open Slat Holder
#5x16mm Self-Tapping Screw (12pcs) -----



Slat Holder (6pc) attach to Side Rails - not shown to scale -----

Open Slat Holder (6pcs) attach to Center Rails - not shown to scale -----


10. Attach Mattress Retainer Bar (A) to Head Frame (B)
M6x50mm Bolt, Washer, Nylock Nut (Single-2 Sets, Double and Queen-4 sets) -----




****Do not attach Leg Actuator Bars (E) at this time****

Section 4: LEG ASSEMBLY


11. Stand the assembled frame. Lift and set the hinge axles of the Head Frame (B) into the hinges of the Yoke Assembly.
12. Stabilize the frame in the vertical position by applying one spring on either side (Photo 1).
13. Attach Legs (N) to Side Rails (D), see Detail A. Do not over tighten so Legs may pivot freely.
M6x42mm Bolt, Spacer, Washer, Nylock Nut (2 sets)




14. Attach Leg Connector Tube (M) to Legs (N) as shown.
M6x16mm Bolt (4 sets)



15. Attach Actuator Bars (E) to the Leg Brackets (N) with bolt sets (see Detail A), then to the Floor Yokes (H) with cotter pins. Bend back ends to secure.
M6x20mm Bolt, T-Nut, Washer, Nylock Nut (2 sets)



16. Rotate the bed down horizontal and install the Slats (Q) by slipping one end into the closed Slat Holder and flexing the slat slightly and tapping it into the open ended Slat Holder.
17. Put Mattress in place and secure with Nylon Web Strap.
18. Install proper number of Springs to balance. Raise bed frame with mattress to the vertical position. Add an equal # of springs on each side until the bed frame is almost weightless at the 45* angle. Remember that the system will weigh slightly more when bedding is added to the system. See Photo 1.
19. Install the Spring Covers (L) to the Bottom Spring Tube (J) to cover the installed springs.
M6x10mm Bolt (4pcs)



20. Adjust the Wall Mount Brackets on the Yoke Assembly to have the bed operate at the minimum distance from the wall. Tighten bolts in place.

Photo 1



First hook bottom of spring in the Bottom Spring Tube (J), then using vice grips pull up and set the top spring hook. You may use leverage from the Yoke Connector Bar (I).

Detail A - not full scale

